

KLOVER MiK 09

Wind Cover Installation

Step 1 – Place the wind cover, fur side down, on a clean, flat surface and unfasten the Velcro strip.



Step 2 – Place the parabolic dish and frame on top of the wind cover and slide the unit inside the wind cover's pocket.



Step 3 – Align the wind cover’s seam with the outside edge of the frame. Ensure that the “ears” of the wind cover match the frame’s “ears” around the thumbscrews..



Step 4 – Pull the two sides of the wind cover together and fasten the Velcro strip.



To remove the wind cover, reverse the process.

I May Need A Fluff!

The face of the wind cover may be flattened during shipment. In most cases, matted fur does not affect the effectiveness of it. However, you can remove the cover from the dish, slip it on your hand, and use a hair drier to fluff it up. Be careful to not touch the hair drier to the wind cover.

Klover Products Inc.
5807 W Fenrick Rd
Janesville, WI 53548
(888) 299-9009
www.KloverProducts.com
support@KloverProducts.com

