

KLOVER MiK 16

Wind Cover Installation

Step 1 – Place the wind cover, fur side down, on a clean flat surface.



Step 2 – Place the dish with mic yoke bar installed, on top of the wind cover. Slide the handle inside the pocket at the top.



Step 3 – Align the connectors with the gaps in the cover. Wrap the edge of the wind cover around the edge of the dish, placing the cording inside of the three connectors. Tighten the pull cord while keeping the spacing / bunching of the individual section relatively equal. Cinch the cord lock and tuck the ends of the cord under the wind cover.



Step 4 – Clear the wind cover material from the quick release connectors and install the handles, or mounting bracket, onto the dish. Make sure the connectors are fully seated.



Step 5 – If a viewing window is included, gently adjust the position of the wind cover, to align the window with the sighting pins on top of the mic yoke hub.

Reverse process to remove the wind cover.

I May Need A Fluff!

The face of the wind cover may be flattened during shipment. In most cases, matted fur does not affect the effectiveness of it. However, you can remove the cover from the dish, slip it on your hand, and use a hair dryer to fluff it up. Be careful to not touch the hair drier to the wind cover.

Klover Products Inc.
5807 W Fenrick Rd
Janesville, WI 53548
(888) 299-9009
www.KloverProducts.com
support @KloverProducts.com

