

KLOVER MiK 26

Wind Cover Installation

Step 1 – Place the wind cover, fur side down, on a clean flat surface.



Step 2 – Place the dish with mic yoke bar installed, on top of the wind cover. Slide the handle inside the pocket at the top.



Step 3 – Align the connectors with the gaps in the cover. Wrap the edge of the wind cover around the edge of the dish, placing the cording inside of the six connectors. Tighten the pull cord and cinch with the cord lock.



Step 4 - Install the mic handles onto the dish, making sure the connectors are fully seated.



Step 5 – Gently adjust the position of the wind cover, to align window with the sighting pins on top of the mic yoke hub.

Reverse process to remove the wind cover.

I May Need A Fluff!

The face of the wind cover may be flattened during shipment. In most cases, matted fur does not affect the effectiveness of it. However, you can remove the cover from the dish, slip it on your hand, and use a hair dryer to fluff it up. Be careful to not touch the hair drier to the wind cover.

Klover Products Inc.
5807 W Fenrick Rd
Janesville, WI 53548
(888) 299-9009
www.KloverProducts.com
support@KloverProducts.com

